


INSTALLATION INSTRUCTIONS



THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
CE PRODUIT DOIT ETRE INSTALLE SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAIT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHERENTS.
DISCONNECT POWER PRIOR TO ANY INSTALLATION.
DEBRANCHEZ LE COURANT AVANT TOUTE INSTALLATION.
CAP ALL WIRING CONNECTIONS WITH UL APPROVED WIRE CONNECTORS.
COUVRIR TOUTES LES CABLES AVE DES CONNECTIONS APPROUVES (UL).
VERIFY SUPPLY VOLTAGE MEETS LUMINAIRE LABEL SPECIFICATIONS.
VERIFIEZ QUE LA TENSION SOIT COMPATIBLE AVEC LES CARACTERISTIQUES DU LUMINAIRE MARQUE SUR LETIQUETTE.
ALLOW FIXTURE TO COOL BEFORE TOUCHING HEATSINK OR LIGHT SOURCE.
LAISSEZ LE PROJECTEUR REFOIDIR AVANT DE TOUCHER LE RADIATEUR OU LA SOURCE DE LUMIERE.
DO NOT ATTEMPT TO OPEN OR MAKE REPAIRS INSIDE LUMINAIRE.
NE PAS TENTER DOUVRIRE OU DE FAIRE DES REPARATINS A L'INTERIEUR DU LUMINAIRE.
AVOID DIRECT VIEWING OF LIGHT SOURCE.
EVITEZ DE REGARDER DIRECTMENT LA SOURCE LUMINEUSE.
THIS PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN.
CE PRODUIT DOIT ITRE INSTALLE PAR UN ELECTRICIEN QUALIFIE.
SUITABLE FOR UNDER-CABINET MOUNT.
ADAPTE POUR SOUS-CABINET MOUNT.
SUITABLE FOR DAMP LOCATION.
ADAOTE POUR DES ENDROITS HUMIDES.
SUITABLE FOR CONTINUOUS ROW MOUNTING.
ADAPTE POUR CONTINUE ROW MONTAGE.

STARTEK
ARCHITECTURAL LIGHTING




AVION D
AVION DI

Note: All pictures shown are of
the AVION D


INSTALLATION INSTRUCTIONS

Individual Pendant Mount (ACxxx)


1 Power must be turned off prior to disconnecting or reconnecting fixture.




2 Locate ceiling mounting points. Connect wire to building mains and then canopy to structure. Remove slack from cord attach strain relief to hole.




3 Power feed side. Secure canopy (A) with threaded coupler (B) on threaded stud (C)




4 Non-power feed side. Secure canopy (D) with cable coupler (E) on threaded stud (F)



5 Level fixture by adjusting aircraft cable through grippers on both ends.




6 Restore power




INSTALLATION INSTRUCTIONS

Individual Rigid Pendant Mount (PMxxx)


1 Power must be turned off prior to disconnecting or reconnecting fixture.




2 Feed power through nipple, stem and connect threaded stem to canopy.




3 Power feed canopy. Secure canopy (A) with threaded stem (B) on magnet (C)




4 Non-power feed side. Secure canopy (D) with threaded stem (E) on magnet (F)



5 Connect non-power stem to canopy.




6 Restore power




INSTALLATION INSTRUCTIONS

Individual Box Mount (BX4)


1 Power must be turned off prior to disconnecting or reconnecting fixture.




2 Fixture is supplied with bottom bracket component installed on fixture.




3 Mount top bracket to structure where line wiring is present.



4 Hang fixture on the top bracket component in the slot provided. Connect wiring.



5 Remove fixture from hanger, slide fixture into top bracket and secure with 2 screws.



6 Attach cover with 1 screw. Restore power.

