INSTALLATION INSTRUCTIONS

STARTEK
ARCHITECTURAL LIGHTING

⚠ WARNING

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
CE PRODUIT DOIT ETRE INSTALLE SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAIT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHERENTS.
DISCONNECT POWER PRIOR TO ANY INSTALLATION.
DEBRANCHEZ LE COURANT AVANT TOUTE INSTALLATION.
CAP ALL WIRING CONNECTIONS WITH UL APPROVED WIRE CONNECTORS.
COUVRIR TOUTES LES CABLES AVE DES CONNECTIONS APPROUVES (UL).
VERIFY SUPPLY VOLTAGE MEETS LUMINAIRE LABEL SPECIFICATIONS.
VERIFIEZ QUE LA TENSION SOIT COMPATIBLE AVEC LES CARACTERISTIQUES DU LUMINAIRE MARQUE SUR LETIQUETTE.
ALLOW FIXTURE TO COOL BEFORE TOUCHING HEATSINK OR LIGHT SOURCE.
LAISSEZ LE PROJECTEUR REFOIDIR AVANT DE TOUCHER LE RADIATEUR OU LA SOURCE DE LUMIERE.
DO NOT ATTEMPT TO OPEN OR MAKE REPAIRS INSIDE LUMINAIRE.
NE PAS TENTER DOUVRIR OU DE FAIRE DES REPARATINS A LINTERIEUR DU LUMINAIRE.
AVOID DIRECT VIEWING OF LIGHT SOURCE.
EVITEZ DE REGARDER DIRECTMENT LA SOURCE LUMINEUSE.
THIS PRODUCT MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN.
CE PRODUIT DOIT ITRE INSTALLE PAR UN ELECTRICIEN QUALIFIE.
SUITABLE FOR UNDER-CABINET MOUNT.
ADAPTE POUR SOUS-CABINET MOUNT.
SUITABLE FOR DAMP LOCATION.
ADAOTE POUR DES ENDROITS HUMIDES.
SUITABLE FOR CONTINUOUS ROW MOUNTING.
ADAPTE POUR CONTINUE ROW MONTAGE.



STARSTRIP


© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048⬥ (877) Startek ⬥ info@starteklightingamerica.com ⬥ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Individual Surface Mount (SM)

STARTEK
ARCHITECTURAL LIGHTING


1 Power must be turned off prior to disconnecting or reconnecting fixture. Remove front pan by removing screws.




2 Attached electrical fitting (supplied by others) to 7/8 hole on top or side of fixture.




3 Install appropriate anchors (supplied by others) must be used when stud/joist are not present.




4 Connect red and blue wires from back-pan to red and blue wires on front pan using provided connectorS.



5 Re-attach front pan.



6 Restore power.




© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048⬥ (877) Startek ⬥ info@starteklightingamerica.com ⬥ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Continuous Surface Mount (SM)

STARTEK ARCHITECTURAL LIGHTING

1 Power must be turned off prior to disconnecting or reconnecting fixture. Remove front pan by removing screws.




2 Attached electrical fitting (supplied by others) to 7/8 hole on top or side of fixture.




Wire Colors (standard)

Black	Hot
White	Neutral
Green	Ground
Purple	+ Dim (0-10v)
Gray	- Dim (0-10v)


3 Install appropriate anchors (supplied by others) must be used when stud/joist are not present.




4 Connect red and blue wires from back-pan to red and blue wires on front pan using provided connectorS.



5 Hang next fixture. Repeat steps 1-3



6 Connect fixtures together with screws and secure them with nuts.




© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048⬥ (877) Startek ⬥ info@starteklightingamerica.com ⬥ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Continuous Surface Mount (SM)

STARTEK ARCHITECTURAL LIGHTING


7 Connectwires from fixture 1 & 2.




8 Re-attach front pan. Prior to fully securing these screws, see next step.



9 Push fixtures together from the ends, and tighten screws shown in step 8 to achieve a tight joint.



10 Restore power




© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048⬥ (877) Startek ⬥ info@starteklightingamerica.com ⬥ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Individual Y-Toggle Mount PO(X)

STARTEK
ARCHITECTURAL LIGHTING


1 Power must be turned off prior to disconnecting or reconnecting fixture.




2 Feed ends of Y-Toggle mount through slots in back of fixture. Hang in desired location.




3 Attached electrical fitting (supplied by others) to 7/8 hole on top or side of fixture. See steps 4 and 5.




4 Top Power: Remove screw & plate to access wiring compartment.



5 Side power: remove front pan. & 7/8 knockout to access wiring compartment.



6 Restore power.




© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048 ◆ (877) Startek ◆ info@starteklightingamerica.com ◆ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Continuous Y-Toggle Mount P0 (X)

STARTEK
ARCHITECTURAL LIGHTING


1 Power must be turned off prior to disconnecting or reconnecting fixture.




2 Feed ends of Y-Toggle mount through slots in back of fixture. Hang in desired location.




3 Attached electrical fitting (supplied by others) to 7/8 hole on top or side of fixture. See steps 4 and 5.




4 Top Power: Remove screw & plate to access wiring compartment.



5 Side power: remove front pan. & 7/8 knockout to access wiring compartment.



6 Hang next fixture. Repeat steps 2




© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048◆ (877) Startek ◆ info@starteklightingamerica.com ◆ www.starteklightingameica.com

INSTALLATION INSTRUCTIONS


Continuous Y-Toggle Mount P0 (X)

STARTEK ARCHITECTURAL LIGHTING


7 Connect fixtures together with screws and secure them with nuts.




8 Connectwires from fixture 1 & 2.




9 Re-attach front pan. Prior to fully securing these screws, see next step.



10 Push fixtures together from the ends, and tighten screws shown in step 9 to achieve a tight joint.



11 Restore power.



© 2023 StarTek Lighting America. All rights reserved. The Information in this document is subject to change without notice.
899 E Park Ave., Libertyville, IL 60048⬥ (877) Startek ⬥ info@starteklightingamerica.com ⬥ www.starteklightingameica.com